Portable Circular Saws WAC 296-807-120

Summary

YOUR RESPONSIBILITY:

Make sure circular saws are safe

You must

Make sure portable circular saws are safe to use	
WAC 296-807-12005	120-2



Portable Circular Saws

Rule

WAC 296-807-12005

Make sure portable circular saws are safe to use

You must

- (1) Use a constant pressure switch to turn on or operate any circular saw using a blade that has a diameter greater than 2 inches.
- (2) Remove cracked saws and saw blades from service.
- (3) Make sure power driven circular saws that have a blade diameter larger than 2 inches have guards above and below the base plate (shoe) as listed in Table 2, Portable circular saw guarding requirements.

Portable Circular Saw Guarding Requirements

Upper Guard	Lower Guard
Covers the blade to the depth of the teeth, except for the minimum arc necessary to allow the base to tilt for bevel cuts.	Covers the blade to the depth of the teeth, except for the minimum arc necessary to allow proper: • Retraction of the guard
	Contact with the work. Automatically and instantly returns to the position covering the blade when the saw is withdrawn from contact with the work.



Exemption:

Guarding requirements in subsection (3) of this section don't apply to saws used in the meat cutting industry to cut meat.